

## Rules for Saturday

PACE TRACTOR/PACE USED IN ALL CLASSES

COLBY CHEESE DAYS RULES APPLY - SIMILAR TO CLOVERLAND (WITH EXCEPTIONS)

\*NO OVER WEIGHT ALLOWANCE GIVEN IN OPEN & SEMI-STOCK CLASSES\*\*

### RULES

Must Have:

-Working governor (Stock & Semi-Stock)

-Kill Switch

Fly wheel protection (Required for open class – highly recommended for other classes)

-Wheelie bars (Required for open class – highly recommended for other classes)

-Wheel weights only (Required in stock class)

Allowed:

-10% over RPM's (Semi-Stock)

-Points and condenser replaced by exciter ignition

Not Allowed:

-No cutting front of lug (All classes)

-No MSD ignition of after-market distributors or electric fuel pumps (Stock Classes)

1) Tractors must be 1970 or older – NO TURBO ALLOWED

2) Anyone caught tampering with a tractor other than theirs, will be disqualified from pulling

3) No steel wheels

4) No reverse tires

5) Engine speed must be controlled by throttle level only. NO strings or wires allowed.

Tractors can pull in any gear, but no shifting or use of torque.

6) Maximum drawbar height is 20" at point of hook. No fast hitches. Minimum of 18" from center of axel to hook. Drawbar MUST be solid – NO MOVEMENT.

7) The front weight bracket of weight cannot exceed 11 feet from the center of the rear axle.

8) Flagmen/track officials/ eliminator operators may stop and disqualify any puller for unsafe driving or unsafe equipment at any time with no measurement.

ALL OFFICIAL DECISIONS ARE FINAL

9) Where weights fall, is the measurement of the pull.

10) Anyone using profanity towards track officials will be disqualified.

11) Anyone refusing to weigh a tractor before pulling or refusing to re-weigh after pulling will be disqualified.

12) Each tractor is limited to one driver per class and two pulls per tractor.

13) No re-pull for first driver in each class. Registration position is pull position.

14) A driver may stop to adjust weights within the first 50 feet of their pull. However, they must restart on their own power.

15) There will be a driver's meeting prior to the pull.

16) All tractors will be inspected at weigh-in, to ensure they meet the above rules.

## Rules for Sunday

### Equipment Rules

- 1) Tractors must be visually stock.
- 2) Maximum draw bar height 20". No backwards tires or duals. No curved stacks. No exhaust pipes pointed down, or out towards spectators.
- 3) Limit of 3 classes per tractor – weight classes being:
  - a. 5000/6000/7500/9500/12500/1300 (5 MPH) and 6500/11000 (7 MPH)
- 4) There will be NO ALLOWANCES for going over weight.
- 5) All drawbars CANNOT have top link or third arm of any kind. Drawbars must be solid. No movement allowed.

### Driver/Track Rules

- 1) All drivers must sign a release form. Drivers under the age of 18 must have a parent/guardians signature. Minimum age, 14.
- 2) Driver's judged to be under the influence of alcohol/drugs will be disqualified for the day.
- 3) Flagman/track officials/eliminator operators may stop and disqualify puller for unsafe driving or usage equipment at any time.
- 4) All decision made by the flagmen/eliminator operators or track officials are final.
- 5) Drivers are to be fully clothed and remain seated at all times while pulling.
- 6) Objects (weights, parts, etc) falling from tractor while pulling will be flagged and measured at that point.
- 7) Tractors not kept under control and in bounds will be flagged and measured at that point.
- 8) First puller of each class has the option to take that pull or re-pull third in the class.
- 9) Drivers have until the first set of cones to stop, make adjustments, and restart. Limit one restart per class.
- 10) Winners of each class are subject to re-weight when it is the decision of the track officials.
- 11) No entry fee refunds, unless due to mechanical breakdown. Subject to official's approval.
- 12) Late entry fee - \$30.00 per class.